




# JPE25-B



JPE25-B-01	Hexagon bolt with flange
JPE25-B-02	Cylinder head cover
JPE25-B-03	Engine oil Strainer
JPE25-B-04	PACKING, BREATHER CHAMBER
JPE25-B-05	Hexagon bolt with flange
JPE25-B-06	CAP, BREATHER CHAMBER
JPE25-B-07	Breather tube
JPE25-B-08	air deflector
JPE25-B-09	Hexagon bolt with flange
JPE25-B-10	Spark plug
JPE25-B-11	Cylinder head
JPE25-B-12	Hexagon bolt with flange
JPE25-B-13	Valve rocker shaft
JPE25-B-14	Valve rocker combination
JPE25-B-15	Valve locker
JPE25-B-16	Retainer, valve spring
JPE25-B-17	Inner spring of valve
JPE25-B-18	Valve oil seal
JPE25-B-19	Valve Kit
JPE25-B-20	Lifter, Valve
JPE25-B-21	Push rod
JPE25-B-22	Air filter casing cover
JPE25-B-23	Stud 1
JPE25-B-24	Stud 2
JPE25-B-25	Carburetor gasket
JPE25-B-26	Heat insulating pad for carburetor
JPE25-B-27	Carburetor gasket
JPE25-B-28	Carburetor
JPE25-B-29	Carburetor gasket
JPE25-B-30	Support plate body of filter element

JPE25-B-31	Hexagon nut with flange
JPE25-B-32	Air filter
JPE25-B-33	Hexagon bolt with flange
JPE25-B-34	COIL ASSY.,IGNNTION
JPE25-B-35	Oil level sensor
JPE25-B-36	Cable cleat
JPE25-B-37	ocation pin
JPE25-B-38	Gasket for cylinder head
JPE25-B-39	Piston
JPE25-B-40	Steel cable baffle ring
JPE25-B-41	Piston pin
JPE25-B-42	Connecting rod
JPE25-B-43	Piston ring combination
JPE25-B-44	Camshaft assy
JPE25-B-45	crankshaft
JPE25-B-46	Bearing
JPE25-B-47	Oil seal
JPE25-B-48	Components of governor gear
JPE25-B-49	Pouring orifice filter screen combination
JPE25-B-50	Crankcase cover gasket
JPE25-B-51	Oil rule combination
JPE25-B-52	Crankcase cover
JPE25-B-53	Hexagon bolt with flange
JPE25-B-54	Crankcase body
JPE25-B-55	FLYWHEEL COMP
JPE25-B-56	Hexagon nut with flange
JPE25-B-57	Manual starting assembly
JPE25-B-58	Pipe clip
JPE25-B-59	Flat washer
JPE25-B-60	Sealing plug screw



JPE25-B-61	Hexagon bolt with flange
JPE25-B-62	Location wire nail
JPE25-B-63	Engine oil protector
JPE25-B-64	throttle return spring
JPE25-B-65	Throttle rod
JPE25-B-66	Speed regulating bracket
JPE25-B-67	Pin clip
JPE25-B-68	Speed regulating arm
JPE25-B-69	Governing spring
JPE25-B-70	Hexagon bolt with flange
JPE25-B-71	Throttle handle combination
JPE25-B-72	Gasket for cylinder head cover
JPE25-B-73	Hexagon nut with flange
JPE25-B-74	Muffler
JPE25-B-75	Side plate
JPE25-B-76	Hexagon bolt with flange
JPE25-B-77	Hexagon bolt with flange
JPE25-B-78	Oil tube
JPE25-B-79	Tank
JPE25-B-80	Tank cover
JPE25-B-81	Outlet gasket
JPE25-B-82	Tank oilout
JPE25-B-83	Hexagon bolt with flange
JPE25-B-84	Air filter seat
JPE25-B-85	Air filter element 1
JPE25-B-86	Air filter element 2
JPE25-B-87	Key
JPE25-B-88	Engine Base

**JPE25-B**