




JPE750HDF 22HP HORIZONTAL SHAFT ENGINE



JPE750HDF-001	Tape, L=150mm
JPE750HDF-002	Bolt, M6×20
JPE750HDF-003	Oil Radiator
JPE750HDF-004	Bolt, M6×30
JPE750HDF-005	O-Ring, φ11.2×2.65
JPE750HDF-006	Secondary Oil Filter
JPE750HDF-007	Connection Pipe
JPE750HDF-008	Bolt, M6×12
JPE750HDF-009	Cylinder Head Baffle Right
JPE750HDF-010	Oil Radiator Bracket
JPE750HDF-011	Spark Plug
JPE750HDF-012	Fuel Hose φ9.5×φ17.4×295
JPE750HDF-013	Clamp
JPE750HDF-014	Fuel Tube Joint
JPE750HDF-015	Washer, φ10.5×2×φ18
JPE750HDF-016	Oil Filter
JPE750HDF-017	Clip
JPE750HDF-018	Crankcase
JPE750HDF-019	Washer, φ14×1.5×φ22
JPE750HDF-020	Earth Bolt
JPE750HDF-021	Oil Sensor
JPE750HDF-022	Bolt, M6×16
JPE750HDF-023	Crankshaft
JPE750HDF-024	Washer, φ38.5×1×φ54
JPE750HDF-025	Bolt, M6×16
JPE750HDF-026	Oil Pump
JPE750HDF-027	Oil Pump Spring
JPE750HDF-028	Steel Ball, φ9.5
JPE750HDF-029	Breather Filter Screen

JPE750HDF-030	Pin, φ8×12
JPE750HDF-031	Gasket, Crankcase
JPE750HDF-032	O-Ring, φ13.2×2.65
JPE750HDF-033	Crankcase Cover
JPE750HDF-034	Oil Seal, φ38×φ58×8
JPE750HDF-035	Pin, φ14×10×φ12.5
JPE750HDF-036	Connecting Rod Bearing
JPE750HDF-037	Bolt, M8×50
JPE750HDF-038	Dipstick
JPE750HDF-039	Washer, φ17.4×1×φ25.9
JPE750HDF-040	Camshaft
JPE750HDF-041	Bolt, M6×25
JPE750HDF-042	Lower Rocker Arm
JPE750HDF-043	Governor Gear
JPE750HDF-044	Bearing, 6003
JPE750HDF-045	Circlip
JPE750HDF-046	Intake Valve
JPE750HDF-047	Pin, φ12×20
JPE750HDF-048	Cylinder Head
JPE750HDF-049	Valve Spring Seat
JPE750HDF-050	Valve Adjust Cap, Exhaust
JPE750HDF-051	Intake Valve Seal
JPE750HDF-052	Valve Spring
JPE750HDF-053	Valve Locker
JPE750HDF-054	Valve Spring Seat
JPE750HDF-055	Bolt, M6×22
JPE750HDF-056	Valve Cover
JPE750HDF-057	Gasket, Valve Cover
JPE750HDF-058	Bush Bracket
JPE750HDF-059	Rocker Arm Assembly



JPE750HDF continued

JPE750HDF-060	Rocker Arm Base
JPE750HDF-061	Bolt, M10x1.25x87
JPE750HDF-062	Bolt, M8x16
JPE750HDF-063	shroud
JPE750HDF-064	Gasket, Cylinder Head
JPE750HDF-065	Exhaust Valve
JPE750HDF-066	Push Rod
JPE750HDF-067	Piston Ring Set
JPE750HDF-068	Piston
JPE750HDF-069	Piston Pin
JPE750HDF-070	Connecting Rod Assembly
JPE750HDF-071	Washer, $\phi 8.5 \times 2 \times \phi 15.8$
JPE750HDF-072	Oil Seal
JPE750HDF-073	Throttle Linkage
JPE750HDF-074	Idle Spring
JPE750HDF-075	Gasket, Intake Manifold
JPE750HDF-076	Intake Manifold
JPE750HDF-077	Gasket, Carburetor
JPE750HDF-078	Insulator
JPE750HDF-079	Carburetor
JPE750HDF-080	Air Filter Tube
JPE750HDF-081	Bolt, M6x90
JPE750HDF-082	Regulator Assembly
JPE750HDF-083	Nut, M6
JPE750HDF-084	Air Filter Assembly
JPE750HDF-085	Throttle Lever Knob
JPE750HDF-086	Switch Box Base
JPE750HDF-087	Wire Harness Jacket
JPE750HDF-088	Intake Tube
JPE750HDF-089	Throttle Governor Lever
JPE750HDF-090	Oil Sensor
JPE750HDF-091	Breather Hose
JPE750HDF-092	Bolt, M6x65
JPE750HDF-093	Stud
JPE750HDF-094	Intake Manifold
JPE750HDF-095	Stud, M8x34
JPE750HDF-096	Bolt, M8x50
JPE750HDF-097	Choke Spring
JPE750HDF-098	Governor Gear Bracket Assembly
JPE750HDF-099	Governor Spring
JPE750HDF-100	Governor Spring
JPE750HDF-101	Choke Linkage Lock Clamp
JPE750HDF-102	Choke Lever
JPE750HDF-103	Governor Lever
JPE750HDF-104	Cotter Pin
JPE750HDF-105	Bearing, HK081210
JPE750HDF-106	Governor Gear Shaft
JPE750HDF-107	Oil Plug
JPE750HDF-108	Valve Cover
JPE750HDF-109	Cylinder Head
JPE750HDF-110	Cylinder Head Baffle Left
JPE750HDF-111	Clamp
JPE750HDF-112	Pin, $\phi 12 \times 10 \times \phi 10$
JPE750HDF-113	Pin, $\phi 10 \times 12$
JPE750HDF-114	Electric Starter
JPE750HDF-115	Air Filter Cover
JPE750HDF-116	Bolt, M8x110
JPE750HDF-117	Bolt, M6x10
JPE750HDF-118	Spray Head Washer
JPE750HDF-119	Washer, $\phi 10.5 \times 1.5 \times \phi 18$

JPE750HDF-120	Clip
JPE750HDF-121	Clamp
JPE750HDF-122	Clamp
JPE750HDF-123	Fuel Hose Jacket
JPE750HDF-124	Fuel Filter
JPE750HDF-125	Lift Hook
JPE750HDF-126	Fuel Hose
JPE750HDF-127	Gasket, Breather Cover
JPE750HDF-128	Breather Valve
JPE750HDF-129	Oil Block
JPE750HDF-130	Breather Cover
JPE750HDF-131	Wire Board
JPE750HDF-132	Bolt, M6x28
JPE750HDF-133	Right Hand Side Ignition Module
JPE750HDF-134	Bolt, M6x18
JPE750HDF-135	Fuel Hose
JPE750HDF-136	Bush, $\phi 6.5 \times \phi 10 \times 24$
JPE750HDF-137	Pulse Pump
JPE750HDF-138	Fuel Hose
JPE750HDF-139	Bolt, M6x40
JPE750HDF-140	Fuel Hose Jacket
JPE750HDF-141	Fuel Pump Bracket
JPE750HDF-142	Bolt
JPE750HDF-143	Choke Plate
JPE750HDF-144	Self-tapping Screw, ST4.2x25
JPE750HDF-145	Charging Coil
JPE750HDF-146	Muffler
JPE750HDF-147	Washer, $\phi 6$
JPE750HDF-148	Nut, M8
JPE750HDF-149	Left Hand Side Ignition Module
JPE750HDF-150	Stud, M6x112.5
JPE750HDF-151	Stud, M6x122
JPE750HDF-152	Flywheel
JPE750HDF-153	Cooling Fan
JPE750HDF-154	Cooling Fan Plate
JPE750HDF-155	Washer, $\phi 20.5 \times 5 \times \phi 40$
JPE750HDF-156	Nut, M20x1.5
JPE750HDF-157	Bolt, M8x20
JPE750HDF-158	Blower Housing
JPE750HDF-159	Shroud
JPE750HDF-160	Nut, M6
JPE750HDF-161	Clamp
JPE750HDF-162	Nut, M6
JPE750HDF-163	Washer, $\phi 6$
JPE750HDF-164	Dust Ejector Valve
JPE750HDF-165	Air Filter Cover
JPE750HDF-166	Air Filter Clip
JPE750HDF-167	Air Filter Element
JPE750HDF-168	Gasket, Air Filter
JPE750HDF-169	Air Filter Bracket
JPE750HDF-170	Air Filter Body
JPE750HDF-171	O-Ring, $\phi 63 \times 2.65$
JPE750HDF-172	Air Filter Outlet Elbow Pipe
JPE750HDF-173	O-Ring, $\phi 120 \times 2$
JPE750HDF-SKIT	Service Kit