


PGEN92ES GENERATOR




1:14

PGEN92ES-G-01	Handle
PGEN92ES-G-02	SpRing Pin
PGEN92ES-G-03	Circlip
PGEN92ES-G-04	Bolt, M6×14
PGEN92ES-G-05	Wheel Support
PGEN92ES-G-06	Wheel Shaft Assembly
PGEN92ES-G-07	Tire
PGEN92ES-G-08	Washer, $\phi 6.5 \times 2 \times \phi 25$
PGEN92ES-G-09	Washer, $\phi 6$
PGEN92ES-G-10	Fuel Switch
PGEN92ES-G-11	Clamp
PGEN92ES-G-12	Fuel Tank
PGEN92ES-G-13	Fuel Meter
PGEN92ES-G-14	Oil Sense Clip
PGEN92ES-G-15	Bolt, M6×25
PGEN92ES-G-16	Fuel Cap
PGEN92ES-G-17	Engine
PGEN92ES-G-18	Self-tappling Screw, ST4.2×19
PGEN92ES-G-19	Cylinder Head Baffle
PGEN92ES-G-20	Bolt, M6×12
PGEN92ES-G-21	Gasket, Muffler
PGEN92ES-G-22	Nut, M8
PGEN92ES-G-23	Muffler
PGEN92ES-G-24	Bolt, M8×16
PGEN92ES-G-25	Brush
PGEN92ES-G-26	Bolt, M5×18
PGEN92ES-G-27	Bolt, M5×14
PGEN92ES-G-28	End Cover
PGEN92ES-G-29	Nylon Washer
PGEN92ES-G-30	Washer, $\phi 5$
PGEN92ES-G-31	Washer, $\phi 5$
PGEN92ES-G-32	Bolt, M6×200
PGEN92ES-G-33	Rear Bracket

PGEN92ES-G-34	Damping Pad
PGEN92ES-G-35	Nut, M10×1.25
PGEN92ES-G-36	Earth Wire
PGEN92ES-G-37	Reinforcement Support
PGEN92ES-G-38	Nut, M8
PGEN92ES-G-39	Bolt, M10×1.25×270
PGEN92ES-G-40	Washer, $\phi 10$
PGEN92ES-G-41	Washer, $\phi 10 \times 4 \times \phi 30$
PGEN92ES-G-42	Alternator
PGEN92ES-G-43	Bolt, M5×240
PGEN92ES-G-44	Nut, M5
PGEN92ES-G-45	Bolt, M10×1.25×25
PGEN92ES-G-46	Front End Cover
PGEN92ES-G-47	Nut, M8
PGEN92ES-G-48	Frame Assembly
PGEN92ES-G-49	Washer, $\phi 6$
PGEN92ES-G-50	Washer, $\phi 6$
PGEN92ES-G-51	Nut, M6
PGEN92ES-G-52	Nut, M6
PGEN92ES-G-53	Damping Pad
PGEN92ES-G-54	Bolt, M8×55
PGEN92ES-G-55	Voltage Regulator
PGEN92ES-G-56	Control Panel
PGEN92ES-G-57	Cathode Wire
PGEN92ES-G-58	Anode Wire
PGEN92ES-G-59	Nut, M6
PGEN92ES-G-60	Binder Plate
PGEN92ES-G-61	Bolt
PGEN92ES-G-62	Battery
PGEN92ES-G-63	Support Base
PGEN92ES-G-64	Support Base
PGEN92ES-G-65	Damping Pad
PGEN92ES-G-66	Bush, $\phi 8 \times \phi 6 \times 12$



PGEN92ES ENGINE



1:13

PGEN92ES-E-01	Bolt, M6×25
PGEN92ES-E-02	Valve Cover
PGEN92ES-E-03	Oil Plug
PGEN92ES-E-04	Bolt, M6×8
PGEN92ES-E-05	Washer
PGEN92ES-E-06	Gasket, Valve Cover
PGEN92ES-E-07	Bolt, M8×50
PGEN92ES-E-08	Rocker Arm Base
PGEN92ES-E-09	Retaining Ring, 12
PGEN92ES-E-10	Rocker Arm Assembly
PGEN92ES-E-11	Rocker Arm Assembly
PGEN92ES-E-12	Rocker Arm Coreshaft
PGEN92ES-E-13	Valve Locker
PGEN92ES-E-14	Valve Spring Seat
PGEN92ES-E-15	Valve Spring
PGEN92ES-E-16	Intake Valve Seal
PGEN92ES-E-17	Exhaust Valve
PGEN92ES-E-18	Intake Valve
PGEN92ES-E-19	Shroud
PGEN92ES-E-20	Bolt, M10×95
PGEN92ES-E-21	Stud, M8×32
PGEN92ES-E-22	Cylinder Head
PGEN92ES-E-23	Spark Plug
PGEN92ES-E-24	Stud, M6-8×110
PGEN92ES-E-25	Gasket, Carburetor Insulator
PGEN92ES-E-26	Insulator
PGEN92ES-E-27	Gasket, Carburetor
PGEN92ES-E-28	Carburetor
PGEN92ES-E-29	Gasket, Air Filter
PGEN92ES-E-30	Stepping Motor Base

PGEN92ES-E-31	Stud, M6×84
PGEN92ES-E-32	Air Filter Assembly
PGEN92ES-E-33	Air Filter Base
PGEN92ES-E-34	Air Filter Clip
PGEN92ES-E-35	Gasket, Air Filter
PGEN92ES-E-36	Air Filter Baffle
PGEN92ES-E-37	Air Filter Element
PGEN92ES-E-38	Air Filter Cover
PGEN92ES-E-39	Nut, M6
PGEN92ES-E-40	Clamp
PGEN92ES-E-41	Stepping Motor
PGEN92ES-E-42	Stepping Motor Cover
PGEN92ES-E-43	Screw, M4×8
PGEN92ES-E-44	Clamp
PGEN92ES-E-45	Fuel Hose $\phi 6.3 \times \phi 12.5 \times 210$
PGEN92ES-E-46	Guide Clamp
PGEN92ES-E-47	Spring
PGEN92ES-E-48	Gasket, Cylinder Head
PGEN92ES-E-49	Pin, $\phi 13 \times 16 \times \phi 10.2$
PGEN92ES-E-50	Push Rod
PGEN92ES-E-51	Tappet
PGEN92ES-E-52	Piston Ring Set
PGEN92ES-E-53	Piston
PGEN92ES-E-54	Circlip
PGEN92ES-E-55	Piston Pin
PGEN92ES-E-56	Connecting Rod Assembly
PGEN92ES-E-57	Breather Hose
PGEN92ES-E-58	Crankshaft
PGEN92ES-E-59	Woodruff Key
PGEN92ES-E-60	Camshaft



PGEN92ES ENGINE CONT'D

PGEN92ES-E-61	Washer, $\phi 38.3 \times 1 \times \phi 54$
PGEN92ES-E-62	Oil Seal, $\phi 38 \times \phi 58 \times 8$
PGEN92ES-E-63	Gasket, Crankcase
PGEN92ES-E-64	Pin, $\phi 9 \times 12$
PGEN92ES-E-65	Bolt, M6 $\times 16$
PGEN92ES-E-66	Pin, $\phi 8 \times 8$
PGEN92ES-E-67	Breather Filter Screen
PGEN92ES-E-68	Oil Pump
PGEN92ES-E-69	Gasket, Oil Pump
PGEN92ES-E-70	Spring
PGEN92ES-E-71	Steel Ball, $\phi 9.5$
PGEN92ES-E-72	Dipstick
PGEN92ES-E-73	Bolt, M8 $\times 45$
PGEN92ES-E-74	Crankcase Cover
PGEN92ES-E-75	Connection Pipe
PGEN92ES-E-76	Oil Filter
PGEN92ES-E-77	Washer, $\phi 17.4 \times 1 \times \phi 25.9$
PGEN92ES-E-78	Balance Shaft
PGEN92ES-E-79	Electric Starter
PGEN92ES-E-80	Breather Valve
PGEN92ES-E-81	One-way Valve Spring
PGEN92ES-E-82	Gasket, Breather Cover
PGEN92ES-E-83	Breather Cover
PGEN92ES-E-84	Bolt, M6 $\times 14$
PGEN92ES-E-85	Crankcase
PGEN92ES-E-86	Oil Pressure Sensor
PGEN92ES-E-87	Washer, $\phi 10 \times 1.5 \times \phi 17$
PGEN92ES-E-88	Clip
PGEN92ES-E-89	Oil Sensor
PGEN92ES-E-90	Drain Bolt
PGEN92ES-E-91	Washer, $\phi 14 \times 1.5 \times \phi 22$
PGEN92ES-E-92	Bolt, M8 $\times 35$
PGEN92ES-E-93	Wire Board
PGEN92ES-E-94	Bolt, M6 $\times 10$
PGEN92ES-E-95	Wire Board
PGEN92ES-E-96	Ignition Module
PGEN92ES-E-97	Bolt, M6 $\times 28$
PGEN92ES-E-98	Charging Coil
PGEN92ES-E-99	Bolt, M5 $\times 25$
PGEN92ES-E-100	Flywheel
PGEN92ES-E-101	Cooling Fan
PGEN92ES-E-102	Starter Cup
PGEN92ES-E-103	Bolt, M6 $\times 14$
PGEN92ES-E-104	Washer, $\phi 20.5 \times 5 \times \phi 40$
PGEN92ES-E-105	Nut, M20 $\times 1.5$
PGEN92ES-E-106	Stud, M8 $\times 105$
PGEN92ES-E-107	Blower Housing
PGEN92ES-E-108	Recoil Starter
PGEN92ES-E-109	Nut, M6

PGEN92ES